DIRECTIONS "The Oil-Fix

"The" Oil Fix is the perfect solution for eliminating oil leaks from between your barrel and gasket. Just follow these simple instructions and you'll never see a leak again. Designed for all Big Twin applications.

STEP 1

Remove barrels and clean all surfaces being careful not to scratch gasket surface.

STEP 2

Install the base gasket that is supplied in the kit.



STEP 3

Install the barrel over the studs and slide down to within about 1" between the base and barrel. Using Blue Loctite or ThreeBond on "The" Oil Fix Bushing, install the bushing with the small end down into the base oil return passage.

CAUTION: Do not drop the bushing into the crankcase.

STEP 4

Slide the barrel down the studs the rest of the way and secure.

"Feel the Difference!"

Hayden Enterprises 840 E. Parkridge Ave #106

Corona, CĂ 92879 www.haydensm6.com (800) M6-IN-USA

> out of USA, call (951)371-0030 fax (951)371-4033